



limhponer / computervision-final-prep



Code

Issues

Pull requests

Actions

Projects

Wiki

Security

In

[computervision-final-prep / lab / Lab 09 \(Tracking\)-20251128 / 9.2\\_single\\_object\\_tracking.py](#)

limhponer lab 9-obj tracking

267755b · 2 hours ago



91 lines (70 loc) · 2.89 KB

Code

Blame



Raw



```
1 import cv2
2 import sys
3
4 (major_ver, minor_ver, subminor_ver) = (cv2.__version__).split('.')
5
6 # For GOTURN, you need to set up the model files.
7 # Download the following files: https://github.com/Mogball/goturn-files
8
9 if __name__ == '__main__':
10
11     # Set up tracker.
12     # Instead of GOTURN, you can also use
13
14     tracker_types = ['BOOSTING', 'MIL','KCF', 'GOTURN']
15     tracker_type = tracker_types[3]
16
17     if int(minor_ver) < 3:
18         tracker = cv2.Tracker_create(tracker_type)
19     else:
20         if tracker_type == 'BOOSTING':
21             tracker = cv2.TrackerBoosting_create()
22         elif tracker_type == 'MIL':
23             tracker = cv2.TrackerMIL_create()
24         elif tracker_type == 'KCF':
25             tracker = cv2.TrackerKCF_create()
26         elif tracker_type == 'GOTURN':
27             tracker = cv2.TrackerGOTURN_create()
28
29     # Read video
30     # video = cv2.VideoCapture("videos/video.mp4")
31     video = cv2.VideoCapture(0)                                # for using CAM
32
```

```
33     # Exit if video not opened.
34     if not video.isOpened():
35         print("Could not open video")
36         sys.exit()
37
38     # Read first frame.
39     ok, frame = video.read()
40     if not ok:
41         print ('Cannot read video file')
42         sys.exit()
43
44     # Define an initial bounding box - if you already know the object location, you can set it
45     # bbox = (287, 23, 86, 320) # Example: (x, y, width, height)
46
47     # Select ROI manually
48     bbox = cv2.selectROI(frame, False)
49
50     # Initialize tracker with first frame and bounding box
51     ok = tracker.init(frame, bbox)
52
53     while True:
54         # Read a new frame
55         ok, frame = video.read()
56         if not ok:
57             break
58
59         # Start timer
60         timer = cv2.getTickCount()
61
62         # Update tracker
63         ok, bbox = tracker.update(frame)
64
65         # Calculate Frames per second (FPS)
66         fps = cv2.getTickFrequency() / (cv2.getTickCount() - timer);
67
68         # Draw bounding box
69         if ok:
70             # Tracking success
71             p1 = (int(bbox[0]), int(bbox[1]))
72             p2 = (int(bbox[0] + bbox[2]), int(bbox[1] + bbox[3]))
73             cv2.rectangle(frame, p1, p2, (255,0,0), 2, 1)
74         else :
75             # Tracking failure
76             cv2.putText(frame, "Tracking failure detected", (100,80), cv2.FONT_HERSHEY_SIMPLEX,
77
78             # Display tracker type on frame
79             cv2.putText(frame, tracker_type + " Tracker", (100,20), cv2.FONT_HERSHEY_SIMPLEX, 0.7,
80
81             # Display FPS on frame
```

```
82         cv2.putText(frame, "FPS : " + str(int(fps)), (100,50), cv2.FONT_HERSHEY_SIMPLEX, 0.75
83
84     # Display result
85     cv2.imshow("Tracking", frame)
86
87     # Exit if ESC pressed
88     if cv2.waitKey(1) & 0xFF == ord('q'): # if press SPACE bar
89         break
90
91     video.release()
91     cv2.destroyAllWindows()
```